

# Installation Instructions

## 1/2" Connectors

716f-S012-A0, 716m-S012-A0, Nf-S012-A0 and Nm-S012-A0  
 716f-S012-B0, 716m-S012-B0, Nf-S012-B0 and Nm-S012-B0  
 Using connecting kit CONK-S012-B0

**For 1/2" superflex cables:** NK Cables RFF 1/2"-50, Andrew FSJ4-50B, Eupen 5092 1/2" Hiflex, Acome HPL 50-1/2 SF, Cablewave S-FLC 12 and Leoni FlexLine 1/2" S

Connecting requires qualified and experienced personnel. Exir Broadcasting & Telecom AB disclaims any liability as a result of improper or unsafe practice.

Document Id: 227-000052

ver. 9

Rev. 081003 MXN

